


If the projector display goes blank while in use...

In addition to setting the **Power** setting in the **Advanced** mode of the **Screen-Saver settings**, do this:

1. Turn off **UDT Protection**.
2. Right-click on the desktop and select **Graphics Properties...** *(It may take a while for the properties settings to show).*
3. Select **Power** on the left side of the window.
4. Select the radio-button **Maximum Performance** as shown.
5. Click on the **Apply** button.
6. Click **OK**.



Remember to check the following:

1. All cable connections from the docking station to the document camera should be tight.
2. All cable connections from the document camera to the junction box at the bottom of the Dualboard should be tight.
3. All cable connections from the junction box at the bottom of the Dualboard to the projector should be tight.
4. Finally, ensure the **laptop is firmly seated on the docking station!**